



chorus™



Couples Vibrator

We-Vibe® Chorus™ is a hands-free couples vibrator that takes you to next-level sex. Chorus is all about giving you exactly what you need to maximize pleasure, together. With an adjustable fit, touch-responsive vibrations and customizable controls, it's the most advanced and intuitive couples vibrator ever.



CUSTOM FIT

Worn during sex, Chorus is adjustable to fit your unique body so you can feel the vibrations right where you want them. The shape is easy to adjust and stays in position once you've found the perfect fit.



SQUEEZE REMOTE

Chorus' Squeeze Remote is designed with the most natural human response in mind – the tighter you squeeze, the stronger the vibration gets.



TOUCH-SENSE

We-Vibe Chorus features unique touch-sensitive receptors. As you play, your movements control the vibrations.



STAY CONNECTED

With the free We-Connect™ app, you can share control of Chorus from anywhere, create custom vibes and play together with other We-Vibe products.



FEATURES


Powerful, rumbly vibrations
Intensify your pleasure with 10+ modes and deep, rumbly vibrations.

Soft-touch silicone
Made with silky smooth silicone that's soft and gentle on your body.

Body-safe
Made with body-safe silicone, free from phthalates and BPA and made without latex.

Waterproof
Chorus is 100% waterproof, making it easy to enjoy anywhere and simple to clean.

Adjustable fit
Worn during sex, Chorus is adjustable to fit your unique body so you can feel the vibrations right where you want them. The shape is easy to adjust, then stays in position once you've found the perfect fit.



USB rechargeable
Convenient and eco-friendly, Chorus is rechargeable with up to 90 minutes of play on a single charge.

Touch-sense
Chorus features unique touch-sensitive receptors located beneath the We-Vibe logo. As you play, your movements control the vibrations. Choose from three Touch-sense modes to find your ultimate pleasure.


Beautifully designed case
For discreet storage, charging and travel.

Low power alert
Know when your Chorus needs a charge, so it's always ready to go when you are.

Squeeze Remote
Change vibration modes as well as the intensity in the heat of the moment. Chorus' Squeeze Remote is designed with the most natural human response in mind – the tighter you squeeze, the stronger the vibration gets. Release your grip and the vibration weakens.

App enabled
With the free We-Connect™ app, you can play and share control of Chorus from anywhere, create custom vibes and play together with other We-Vibe™ products. Vibe to music with Beat mode or use Touch mode for real-time control at your fingertips.

Better connectivity
Chorus is powered with AnkorLink™ technology. AnkorLink creates the most stable connection between your We-Vibe and the We-Connect™ app. The Squeeze Remote is the anchor between Chorus and the We-Connect app – you'll need to keep it close by whenever you're using We-Connect.



PRODUCT SPECS

Materials
Body-safe silicone. Free from phthalates and BPA and made without latex.

Vibrator battery
USB rechargeable lithium ion battery.

Run time
Up to 90 mins.


Charge time
90 mins.

2-year warranty

Dimensions
Massager: 78 x 33 x 43.5 mm
Remote: 37 x 96 mm
Case: 91 x 57 x 104 mm

Weight
Massager: 69 g
Remote: 55 g
Case: 108 g

HOW IT'S MEASURED



VIBRATION MODES

